
ANY EnGenius EP436 HANDSET
MENU
EXT 10 & 11 ONLY
MENU
1
LOCK KEYPAD
2
PHONE-BOOK VIEW/SEARCH/ EDIT/DELETE
3
LAST 10 CALLS ON HANDSET
4
SOUND SETTINGS
5
HANDSET SETTINGS
6
REG/DEREG
7
SMS
9
ADMIN. MENU
1=RINGER VOL/VIB.
2=RINGER TONE
3=KEY PRESS VOL
4=KEY PRESS TONE
SEE REG/DEREG. SECTION FOR INSTRUCTIONS
1
LAST 10 DIALLED
2
LAST 10 RECEIVED
3
LAST 10 MISSED
1=ERASE
2=DATE/TIME
3=EDIT &/OR SAVE
1=DIALLING PREFIX
2=SUBSCRIBE TO A GROUP
3=CALL FWD ON/OFF
4=CLEAR ALL LOGS
5=POWER-UP LCD DISPLAY
6=LCD CONTRAST
7=BACK-LIGHT SETTING
1= MESSAGE INBOX
2= MESSAGE OUTBOX
1= ERASE
2=EDIT &/OR SAVE
3=SHOW FULL NUMBER
1=ERASE
2=DATE/TIME
3=EDIT &/OR SAVE
SEE ADMINISTRATOR SECTION FOR USER INSTRUCTIONS